


INK cartridges INK cartridges INK cartridges



INKJET CARTRIDGES

Our Code		OEM Code	Colour	Printer Compatibility
EMJ-003B		T016401	●	Epson Stylus Color 900, 900N/G, 950, 980
EMJ-005C		T017401	● ● ●	Epson Stylus Color 900, 900N/G, 950, 980
EMJ-007B		T017401	●	Epson Stylus Photo 790, 870, 870SE, 875DC, 890, 895, 900, 915, 1270, 1290/S
EMJ-008C		T019401	● ● ● ● ●	Epson Stylus Photo 790, 870, 870SE, 875DC, 890, 895, 915
EMJ-009C		T020401	● ● ● ● ●	Epson Stylus Photo 900, 1270, 1290, 1290/S
EMJ-013B		T026401	●	Epson Stylus Color 480, 580, C20, C40
EMJ-014C		T27401	● ● ●	Epson Stylus Color 480, 580, C20, C40
EMJ-015B		T015401	●	Epson Stylus Photo 2000P





Our Code		OEM Code	Colour	Printer Compatibility
EMJ-016C		T016401		Epson Stylus Photo 2000P
EMJ-017B		T017401		Epson Stylus Color 680, 685, 777/i
EMJ-018C		T017401		Epson Stylus Color 680, 685, 777/i
EMJ-019B		T019401		Epson Stylus Color 880 / 880i
EMJ-020C		T020401		Epson Stylus Color 880 / 880i
EMJ-026B		T026401		Epson Stylus Color C50, PHOTO 810, 820, 830, 925, 935
EMJ-027C		T27401		PHOTO 810, 820, 830, 925, 935
EMJ-028B		T028401		Epson Stylus Color C60, C61

Our Code		OEM Code	Colour	Printer Compatibility
EMJ-029C		T029401		Epson Stylus Color C50, C60
EMJ-T036B		T036140		Epson Stylus Color C42, C44, C46
EMJ-T037C		T037140		Epson Stylus Color C42, C44, C46
EMJ-T038B		T03814A		Epson Stylus Color C41, C43, C45
EMJ-T039C		T03904A		Epson Stylus Color C41, C43, C45
EMJ-T040B		T040140		Epson Stylus Color C62, CX3200
EMJ-T041C		T041040		Epson Stylus Color C62, CX3200
EMJ-321B		T032140		Epson Stylus Color C70, C80, C82, CX5200 CX5400

Our Code		OEM Code	Colour	Printer Compatibility
EMJ-322C / 323M / 324Y		T032240 T032340 T032440		Epson Stylus Color C70, C80
EMJ-T0422C / T0423M / T0424Y		T042240 T042340 T042440		Epson Stylus Color C82, CX5200, CX5400
EMJ-T0431B		T043140		Epson Stylus C84, C84 Photo Ed, C86, C86 Photo Ed, CX3600, CX6400, CX6600
EMJ-T0442C / T0443M / T0444Y		T044240 T044340 T044440		Epson Stylus C84, C84 Photo Ed, C86, C86 Photo Ed, CX3600, CX6400, CX6600, C64, C64 Photo Ed, C66
EMJ-T0441B		T044140		Epson Stylus C64, C64 PE, C66, C84, C84 PE, C86, C86 PE, CX3600, CX6400, CX6600
EMJ-T0452C / T0453M / T0454Y		T045240 T045340 T045440		Epson Stylus C64, C64 PE, C66, C84, C84 PE, C86, C86 PE, CX3600, CX6400, CX6600
EMJ-T0461B / T0472C / T0473M / T0474Y		T04614A T04724A T04734A T04744A		Epson Stylus Color C63, C83, C83 PE
EMJ-T0481B / T0482C / T0483M / T0484Y / T0485PC / T0486PM		T048120 T048220 T048320 T048420 T048520 T048620		Epson Stylus Photo R200, R300, R300 ME, R500, RX500, RX600

Our Code		OEM Code	Colour	Printer Compatibility
EMJ-T0540WF / T0541B / T0542C / T0543M / T0544Y / T0547R / T0548MB / T0549BL		T054020, T054120, T054220, T054320, T054420, T054520, T054620, T054720, T054820, T054920		Epson Stylus Photo R800
PE-T0551B / PE-T0552C / PE-T0553M / PE-T0554Y		T055140 T055240 T055340 T055440		Epson Stylus R240 / 245 RX420 / RX425 / 520
EMJ-T0331B / T0332C / T0333M / T0334Y / T0335LC / T0336LM		T033140 T033240 T033340 T033440 T033540 T033640		Epson Stylus Photo 950, 960
EMJ-341B /PB 342C / 343M / 344Y / 345LC / 346LM / 347LB / 348MB		C13T034180 C13T034280 C13T034380 C13T034480 C13T034580 C13T034680 C13T034780 C13T034880		Epson Stylus Photo 2100
EMJ-T0491B / EMJ-T0492C / EMJ-T0493M / EMJ-T0494Y / EMJ-T0495LC / EMJ-T0496LM		T0491 T0492 T0493 T0494 T0495 T0496		Epson Stylus Photo R210 / R230 / R310 / R350 / RX510 / RX630
EMJ-T557		T557040		PictureMate, Deluxe Viewer Edition; Express Edition
EMJ-T0561B / EMJ-T0562C / EMJ-T0563M / EMJ-T0564Y		T0561 T0562 T0563 T0564		Epson Stylus Photo R250 / RX430 / RX530
EMJ-T0611B-HC EMJ-T0611B / EMJ-T0612C / EMJ-T0613M / EMJ-T0614Y		Own Product T061140 T061240 T061340 T061440		Epson Stylus D68 PE / D88 / D88 Photo Edition / DX3800 / DX3850 / DX4800 / DX4850

Our Code	Image	OEM Code	Colour	Printer Compatibility
EMJ-T0621B-HC EMJ-T0631B / EMJ-T0632C / EMJ-T0633M / EMJ-T0634Y		Own Product T06314A T06324A T06334A T06344A		Epson Stylus C67 / C87 / CX4100 / CX4700
EMJ-T066B EMJ-T067C		T066140 T067140		Epson Stylus Colour C48
EMJ-T0601B EMJ-T0602C EMJ-T0603M EMJ-T0604Y		T0601 T0602 T0603 T0604		Epson Stylus Colour C88
EMJ-T5591B EMJ-T5592C EMJ-T5593M EMJ-T5594Y EMJ-T5595LC EMJ-T5596LM		T559140 T559240 T559340 T559440 T559540 T559640		Epson Stylus Photo RX700
EMJ-T0598 EMJ-T0591 EMJ-T0597 EMJ-T0599 EMJ-T0592 EMJ-T0593 EMJ-T0594 EMJ-T0596 EMJ-T0595		T059840 T059140 T059740 T059940 T059240 T059340 T059440 T059640 T059540		Epson Stylus Photo R2400
EMJ-118B / 122Y / 130C / 126M		S020118 S020122 S020130 S020126		Epson Stylus Color 3000, Stylus Pro 5000, Color Proofer 5000, MJ-8000c
EMJ-460B / 463C / 462M / 461Y / 464LM / 465LC		T460011 T463011 T462011 T461011 T464011 T465011		Epson Stylus Pro 7000, 7000S, Color Proofer 7000/S
EMJ-480B / 483C / 482M / 481Y / 484LM / 485LC		T480011 T483011 T482011 T481011 T484011 T485011		Epson Stylus Pro 7500, Color Proofer 7500, 7500/S

Our Code	Image	OEM Code	Colour	Printer Compatibility
EMJ-407B / 410C / 409M / 408Y / 411LM / 412LC		T407011 T410011 T409011 T408011 T411011 T412011		Stylus Pro 9000, Color Proofer 9000
EMJ-4740B / EMJ-4770C / EMJ-4760M / EMJ-4750Y / EMJ-4780LM EMJ-4790LC		T474011 T477011 T476011 T475011 T478011 T479011		Stylus Pro 9500, Color Proofer 9500